DIAGRAM 6= CONNECTION SHOWING A DMX DESK DRIVING THE DMX>DFB INTERFACE.



IN THIS SYSTEM THE DMX DESK WILL RUN THE DFBs UNTILL IT IS EITHER DISCONNECTED OR TURNED OFF, WHEN THE MEMORY UNIT WILL AUTOMATICALLY TAKE OVER. THIS WILL ONLY HAPPEN IF THE DMX ADDRESS HAS BEEN SET WITHIN THE RANGE SHOWN FOR EITHER CD01 OR CD02 OPERATION.